



# HyperCyl<sup>®</sup>

*By Aries Engineering Company, Inc.*



# **HPS/HPX Series Pneumatic Schematics**

# **Table of Contents**

**Master Control Sequence.....2**

**HPS/HPX 2 Position Spring Return.....3**

**HPS/HPX 2 Position Spring Return ELT.....4**

**HPS/HPX 2 Position Spring Return PT.....5**

**HPS/HPX 2 Position Spring Return w/ 2HNTD & PT....6**


**HPS/HPX 3 Position Open Center.....7**

**HPS/HPX 3 Position Open Center w/ RL.....8**

**Contact Information.....9**

# Master Control Sequence

The HPI, HPS and HPT HyperCyl® cylinders require two (2) pneumatic 4-way directional control valves and a plant air supply for proper operation. The HZ series HyperCyl® cylinder requires only one (1) pneumatic 2-way directional control valve.



Control sequence to be followed in order 1 through 5

Step number	Description of operation	A1 port condition	B1 port condition	A2 port condition	B2 port condition
1.	Home (retracted)	Exhausted	<b>Pressurized</b>	Exhausted	<b>Pressurized</b>
2. (Cycle Start)	Fast Approach extend	<b>Pressurized</b>	Exhausted	Exhausted	<b>Pressurized</b>
3.	High Pressure extend	<b>Pressurized</b>	Exhausted	<b>Pressurized</b>	Exhausted
4. (Cycle End)	Fast Approach retract	Exhausted	<b>Pressurized</b>	<b>Pressurized</b>	Exhausted
5.	High Pressure retract	Exhausted	<b>Pressurized</b>	Exhausted	<b>Pressurized</b>
	(Cylinder now at Step 1)				

Notes for 3 position exhaust-centered valves, for e-stops or light curtain breaches:


**In cycle** (steps 2 through 5).

The mid position of the valves is used only for an E-Stop condition (cycle interrupted), or shutdown. Normally, the valve is shifted to one side or the other, and not in the mid position.


**Not in cycle** (step 1)

When not in cycle, and the e-stop is cleared, B1 and B2 must return to their pressurized condition prior to the start of the cycle. For example, the operator breaches the light curtain to load, unload, or change a part. The machine is not in cycle. The valves shift to their mid position. When the operator is clear of the light curtain, the valves must be shifted to the position in which B1 and B2 are pressurized before the start of the next cycle.


# HPS/HPX 2-Position Spring Return Schematic




# HPS/HPX 2-Position Spring Return ELT Schematic




# HPS/HPX 2-Position Spring Return PT Schematic



# HPS/HPX 2-Position Spring Return 2HNTD with PT Schematic




# HPS/HPX 3-Position Open Center Schematic





# HPS/HPX 3-Position Open Center with Ram Lock Schematic



# Contact Information

**Aries Engineering Co., Inc.  
130 Aries Drive  
Dundee, MI 48131**

**Phone: (734) 529-8855**

**Fax: (734) 529-8844**

**E-Mail: [service@hypercyl.com](mailto:service@hypercyl.com)**

**[www.HyperCyl.com](http://www.HyperCyl.com)**



**HyperCyl®**

*By Aries Engineering Company, Inc.*